
870/50001/2 04/22



BELLE ALTRAD GPX TEST UNIT



GB Operators Manual

UKCA Declaration of Conformity

EU Declaration of Conformity



Declaration Of Conformity (DOC)

We, **Altrad Belle, Sheen, Nr. Buxton, Derbyshire, SK17 0EU, GB** declare that the DoC is issued under our sole responsibility and belongs to the followings product(s):



PRODUCT TYPE	
MODEL	
SERIAL No	
DATE OF MANUFACTURE	
SOUND POWER LEVEL MEASURED / (GUARANTEED)	
WEIGHT	

Object of the Declaration:

Portable dual-voltage tester designed to offer easy voltage, frequency and amp readings from a Generator output.

The object of the declaration described above is in conformity with the relevant **Statutory Requirements**:

- 2016 No. 1101 Electrical Equipment (Safety) Regulations 2016
 - 2016 No. 1091 Electromagnetic Compatibility Regulations 2016

- 2012 No. 3032 The Restriction of the Use of Certain Hazardous Substances in

Electrical and Electronic Equipment Regulations 2012

The following designated standards and technical specifications have been applied:

- BS EN 61010 Safety requirements for electrical equipment for measurement, control

and laboratory use.

- BS EN 61326-1:2013 Electrical equipment for measurement, control and laboratory use.

EMC requirements. General requirements.

Technical Files are held by **Ray Neilson** at the Altrad Belle address stated above:-

Place of Declaration:-

Sheen, Nr. Buxton, Derbyshire, SK17 0EU, UK

Date of Declaration:-

February 2022

Signed by:

Ray Neilson

Managing Director On behalf of Altrad Belle Sheen, Derbyshire, UK



EU Declaration Of Conformity (DOC)



We, **Altrad Belle, Sheen, Nr. Buxton, Derbyshire, SK17 0EU, GB** declare that the DoC is issued under our sole responsibility and belongs to the followings product(s):

7

	,,	
PRODUCT TYPE	/ 	
MODEL		
SERIAL No		:
DATE OF MANUFACTURE		
SOUND POWER LEVEL MEASURED /(GUARANTEED)		
WEIGHT		;

Object of the Declaration:

Portable dual-voltage tester designed to offer easy voltage, frequency and amp readings from a Generator output.

The object of the declaration described above is in conformity with the relevant **Union Harmonisation Legislation**:

- 2014/35/EU Low Voltage Directive

- 2014/30/EU Electromagnetic Compatibility Directive

- 2011/65/EU Restriction of the Use of certain Hazardous Substances in Electrical

and Electronic Equipment (RoHS) Directive 2002/95/EC

The following harmonised standards and technical specifications have been applied:

- BS EN 61010 Safety requirements for electrical equipment for measurement, control

and laboratory use.

- BS EN 61326-1:2013 Electrical equipment for measurement, control and laboratory use.

EMC requirements. General requirements.

Technical Files are held by **Hugues Menager** at the following address:-

Altrad (Group Holding), 125 Rue du Mas Carbonnier, 34000, Montpellier, France.

Place of Declaration:-

Sheen,

Nr. Buxton, Derbyshire,

SK17 0EU,

UK

Date of Declaration:-

March 2022

Signed by:

Ray Neilson

Managing Director On behalf of Altrad Belle Sheen, Derbyshire, UK



How To Use This Manual

This manual has been written to help you operate and service the GPX Test Unit safely.

This manual is intended for dealers and operators of the GPX Test Unit.

Foreword

The 'Machine Description' section helps you to familiarise yourself with the machine's layout and controls.

The 'Environment' section gives instructions on how to handle the recycling of discarded apparatus in an environmentally friendly way.

The 'General Safety' section explains how to use the machine to ensure your safety and the safety of the general public.

The 'Servicing' section is to help you with the general maintenance and servicing of your machine.

The 'Warranty' Section details the nature of the warranty cover and the claims procedure.

The 'CE certificate' section shows the standards that the machine has been built to.

Directives with regard to the notations.

Text in this manual to which special attention must be paid are shown in the following way:



CAUTION

The product can be at risk. The machine or yourself can be damaged or injured if procedures are not carried out in the correct way.



WARNING The life of the operator can be at risk.



WARNING



WARNING

Before you operate or carry out any maintenance on this machine YOU MUST READ and STUDY

KNOW how to safely use the unit's controls and what you must do for safe maintenance. (NB Be sure that you know how to switch the machine off before you switch on, in case you get into difficulty.)

ALWAYS wear or use the proper safety items required for your personal protection. If you have ANY QUESTIONS about the safe use or maintenance of this unit, ASK YOUR SUPERVISOR OR CONTACT: Altrad Belle (UK): +44 (0) 1298 84606


Contents

How to use this manual	4
Varning	
Machine Description	5
Environment	5
Fechnical Data	
General Safety	7
Operating Instructions	
Servicing	9
Narranty	9
Replacement Parts	9
JKCA Declaration of Conformity	2
FU Declaration of Conformity	

Altrad Belle reserves the right to change machine specification without prior notice or obligation.

Machine Description





Environment



Safe Disposal.




Instructions for the protection of the environment. The machine contains valuable materials. Take the discarded apparatus and accessories to the relevant recycling facilities.

Component	Material
Main Body	Steel
Meter Protector	Polycarbonate
Meters	Polycarbonate & Copper
Plugs & Sockets	Polypropylene
Cables	PVC & Copper
Various Parts	Steel and Plastic



Technical Data



Model	GPX Test Unit
A - *Overall Length (mm)	285
B - *Overall Width (mm)	225
C - *Overall Height (mm)	280
Weight (Kg)	4.1
Nominal Voltage (v)	110 / 230
Phase	1
Frequency (Hz)	45 - 65
Current (A)	0 - 40
Max Load Rating (kW)	4.5
Output Sockets - 16A 110v	1
Output Sockets - 16A 230v	1
Cable Length (m)	2
110v Circuit Breaker (A)	35
230v Circuit Breaker (A)	20
Application	Portable Generator Testing

^{*} These figures don't include the Cables.

General Safety



For your own personal protection and for the safety of those around you, please read and ensure you fully understand the following safety information. It is the responsibility of the operator to ensure that he/she fully understands how to operate this equipment safely. If you are unsure about the safe and correct use of the Test Unit, consult your supervisor or Altrad Belle.



CAUTION

Improper maintenance or use can be hazardous. Read and Understand this section before you perform any maintenance, service or repairs.

- Become familiar with the controls before operating the Test Unit.
- Ensure all covers are fitted and IMMEDIATELY replace any missing / damaged parts prior to use.
- Check all cables for signs of damage and IMMEDIATELY replace if necessary.
- Ensure that cables are carefully laid out avoiding liquids, sharp edges and places where vehicles might run over. Unroll it fully or it could catch fire.
- Remove all packaging material before operating.
- Remove any combustible materials from the test area.
- Connect supply to approved IEC60309-2 Plug / Socket Connectors. Either 100v-130v 50-60Hz Yellow 16A rated, or 200v-250v 50-60Hz Blue 16A rated. 2P +E pattern.



WARNING DO NOT operate the Test Unit in wet conditions. This may result in serious injury or even death!

SAFETY AND ACCIDENT PROTECTION

Operating Instructions:

All persons who apply, assemble, operate, start, control, maintain or repair this machine must read and understand these operating instructions.

Owner Responsibility:

The owner must ensure that only competant / trained / qualified persons operate, maintain, or repair this machine.

Storage:

When not in use, store in a dry, locked place. Keep away from children.

Operation for the Intended Purpose:

This Test Unit is designed to make perforance tests (Volt / Frequency (Hz) / Current (A)) of portable Generators.

Transport:

Ensure the carry handle is used when moving the Test Unit.



Operating Instructions



WARNING

Before you operate or carry out any maintenance on this machine YOU MUST READ and STUDY this manual.



Ensure any appliance being tested is in a good serviceable condition before beginning any test procedures.

PRE-OPERATION

- Check your Test Unit before use and **IMMEDIATELY** replace any damaged parts.
- Take the Test Unit to a suitable area for operation, ideally on firm level ground.
- With the Generator switched off, connect the Test Unit power leads (male) to the Generator (110v & 230v respectively).

OFF-LOAD CHECK

- With the Test Unit Voltage Selector in the off position (central position), start the Generator as normal (refer to relevant Generator Operators Manual)
- When the Generator is operating and with the correct voltage selected on the Generator (if applicable), turn the Test Unit on to the desired test voltage also.

The Test Unit should now output Volts and Frequency (Hz)

This procedure can now be replicated for the alternative voltage (if applicable)

NOTE: Make adjustments to the Generator to achieve the desired outputs in-line with the OEM specifications

ON-LOAD CHECK

Connect a suitably sized *piece of equipment for the Generator being tested to the Test Unit (either 110v or 230v).

This must also be:-< 35 Amp for 110v (Max. 4.5kW)

< 20 Amp for 230v (Max. 4.5kW)

*For example, a Generator with PRP of 2.2kW - the appliance rating should not exceed 2.2kW (9.6 Amp)

Recommended appliances for load testing are Heater Elements or Lights with known power ratings.


- With the Test Unit Voltage Selector in the off position (central position), start the Generator as normal (refer to relevant Generator Operators Manual)
- With the Generator operating and with the correct voltage selected on the Generator (if applicable), turn the Test Unit on to the desired test voltage also.

The Test Unit should now output Volts and Frequency (Hz), now turn on the connected appliance and Current (A) can also be read from the Test Unit. This is the required current (Amp) to run the appliance, not the max. of the Generator.

This procedure can now be replicated for the alternative voltage (if applicable)

NOTE: Make adjustments to the Generator to achieve the desired outputs in-line with the OEM specifications.

OPERATIONAL FLOW



Servicing



Before starting any maintenance or repairs, isolate from the all power supplies. On completion of maintenance, check that the Test Unit functions correctly and that all covers are correctly fitted.

RE-SETTING MINIATURE CIRCUIT BREAKERS (MCB); INSTRUMENT FUSE

• The MCB's are provided for both short circuit or overload protection. Should either MCB trip, you may be overloading the Test Unit. Check applied load is < 4.5kW. If the MCB does trip, remove the load, allow the unit to cool and reset the Breaker by pushing the reset button on the rear of the Test Unit above the relevant socket.

Furthermore, there may be faults on the Generator which may need to be investigated by a competant person in-line with the OEM fault finding procedures.

Warranty



Your new Altrad Belle GPX Test Unit is warranted to the original purchaser for a period of one-year (12 months) from the original date of purchase. The Altrad Belle warranty is against defects in design, materials and workmanship.

The following are not covered under the Altrad Belle warranty:

- 1. Damage caused by abuse, misuse, dropping or other similar damage caused by or as a result of failure to follow assembly, operation or user maintenance instructions.
- 2. Alterations, additions or repairs carried out by persons other than Altrad Belle or their recognised agents.
- 3. Transportation or shipment costs to and from Altrad Belle or their recognised agents, for repair or assessment against a warranty claim, on any machine.
- 4. Materials and/or labour costs to renew, repair or replace components due to fair wear and tear.

Altrad Belle and/or their recognised agents, directors, employees or insurers will not be held liable for consequential or other damages, losses or expenses in connection with or by reason of or the inability to use the machine for any purpose.

Warranty Claims

All warranty claims should firstly be directed to Altrad Belle, either by telephone, by Fax, by Email, or in writing.

For warranty claims:

Tel: +44 (0)1298 84606 Fax: +44 (0)1298 84073 Email : Warranty@belle-group.co.uk

Write to:

Altrad Belle Warranty Department, Sheen, Nr. Buxton, Derbyshire, SK17 0EU England.

Warranty Registration:

In the bid for ALTRAD Belle to become greener and more eco friendly, we have now introduced online Warranty registration. To access the registration page of our website, please use the following address:-

http://www.bellegroup.com/index.php?p=warranty_registration

Alternatively, please scan the adjacent QR Code (Quick Response Code) using your smartphone to access the registration page.



Replacement Parts



When maintaining this product only the manufacturers original, genuine replacement parts may be used.

The user will lose any possible claims if replacement parts used are other than the makers original replacement parts.

Replacement parts for this product can be ordered online 24 hours a day, 7 days a week at www.Altrad-Belle247.com

For more information regarding the availability of replacement parts for this product, please contact Altrad Belle using the following contact details:-

Tel:- +44 (0)1298 84606

Fax:- +44 (0)1298 84073

Email:- sales@altrad-belle.com

Alternatively, please scan the adjacent QR Code (Quick Response Code) using your smartphone to access the Altrad Belle online parts portal.





ALTRAD BELLE

Sheen, Nr. Buxton, Derbyshire, SK17 0EU, GB Tel. +44 (0)1298 84606 - Fax +44 (0)1298 84722 - Email: sales@altrad-belle.com www.Altrad-Belle.com

EU IMPORTER ADDRESS

ADRESSE DE L'IMPORTATEUR - DIRECCIÓN DEL IMPORTADOR - ENDEREÇO DO IMPORTADOR - ADRES IMPORTEUR IMPORTØRENS ADRESSE - IMPORTEUR ADRESSE - INDIRIZZO DELL'IMPORTATORE - IMPORTÖRENS ADRESS - IMPORTØRADRESSE MAAHANTUOJAN OSOITE - ADRES IMPORTERA - IMPORTIJA AADRESS - IMPORTÊTĀJA ADRESE - IMPORTUOTOJO ADRESAS ADRESA DOVOZCE - ADRESA IMPORTATORULUI - IMPORTŐR CÍME - ADRESA UVOZNIKA - ÎTHALATÇI ADRESI - ADRESA DOVOZCU

ALTRAD (Group Holding)

125, Rue du Mas Carbonnier, 34000, Montpellier, France Tel. +33 (0) 4 67 50 53 66 - Email: admin@altrad.com www.altrad.com